



| | | | | | |
|--------|--|-------------|----------|--|---------------|
| T1 | Power Transformer | TF-135P | (2) | Speakers, 10" 8 ohm | S-12197 |
| T2 | Output Transformer | TF-531-0 | (1) | Speaker, 15", 16 ohm | S-0128 |
| L1 | Filter Choke | TF-3021H | R61 | 10 meg reversed audio (bass) control | C-BA-811-3710 |
| L1, L2 | Inductances 3.7 mh | | R58, R66 | 250K audio taper (volume and depth) control | C-BA-811-3701 |
| | | | R57 | 2 meg reversed audio (BASS) control | C-BA-811-3781 |
| S1 | Switch - off, standby, on-on | SW-78 | R62, R60 | 500K audio taper (volume and treble) control | C-BA-811-3707 |
| | | | R64 | 1 meg audio taper (treble) control | C-BA-811-3709 |
| LDR-1 | Light Dependent Resistor Lamp Assembly | RE-LDR-430G | R67 | 1.5 meg reversed audio (frequency) control | C-BA-811-3711 |
| | | | R65 | 500 ohm wire wound control | C-B-233 |





Ediphone Model EA-500T